



*** Installation of WIFI Driver**


1) Run a 'Setup.exe' file in a WIFI driver folder.




2) Select a setup language as 'English' and click a 'Next' button.




3) Select an 'I accept the terms of the license agreement' radio button. And click a 'Next' button.




4) Select a 'Ralink Configuration Tool' radio button. And click a 'Next' button.




5) Select an 'Optimize for WIFI mode' radio button. And click a 'Next' button.




6) Click an 'Install' button.




7) Installation procedure is proceeding.



8) Click a **'Finish'** button.




9) After a driver installation procedure is finished, a setup dialog of wireless network appears automatically like below.




10) Select a 'SSID' of network you want to select on the list. And click a 'Connect' button.


(※ 'SSID' is a name of wireless network.)




11) If your 'wireless network' has a password, Choose a password format like 'ASCII' or 'Hexadecimal' like below.



12) Insert a password and click an 'OK' button.



13) If a wireless network is connected successfully, current 'wireless network' information is shown like below.



14) You can find that 'Wireless Network Connection' icon is changed to 'Connected' in 'Network Connection' window.

