
PLU Cost Price Feature

With this feature, you can enter PLU cost price and keep track the PLU profit and profit ratio on the PLU reports. The SPS-2000 has 20 price levels; when using this feature one level is assigned to contain the PLU cost.

1. In REPORT OPTIONS, select a price level which holds PLU cost price. Value '0' in this field means there is no cost price entry in PLU.

The screenshot shows a software interface titled "REPORT OPTIONS" with a light blue background. At the top, there are three tabs: "PAGE #1", "PAGE #2", and "PAGE #3". Below the tabs, there is a list of settings, each with a corresponding button to its right. The settings are:

Setting	Value
16. ALLOW Z1 TIME KEEPING REPORT WHEN EMPLOYEES ARE CLOCKED IN	NO
17. AVG.GST ON FIN IS FROM GST	NO
18. ALLOW Z WITH OPEN CLERKS	NO
19. MAKE IRC REPORT IN DEFAULT?	NO
20. MGR REQUIRED FOR IRC SETTING?	NO
21. CLEAR GLOBAL ORDER# AFTER Z1 FIN	NO
22. EXCLUDE TAX ON TIME PERIOD REPORT	NO
23. PLU COST PRICE LEVEL (0 - 20)	04

A black arrow points to the "04" value in the "PLU COST PRICE LEVEL" row. At the bottom of the screen, there is a "CLOSE" button.

2. Set REPORT PRINTING OPTIONS/14. PRINT PLU PROFIT ON PLU REPORT to **YES**.

REPORT PRINTING OPTIONS	
PAGE #1	PAGE #2
5. INDIV ITEM USAGE QTY ON PLU RPT	NO
6. COUNT ON TIME REPORT IS	CUSTOMER
7. USE FUNCTION KEY DESCRIPTOR IN RPT	REPORT DESCRIPTOR
8. PRINT MIN.STK RPT AFTER FINAN. RPT	NO
9. PRINT GRAND TOTAL ON FINANCIAL RPT	YES
10. PRINT GROUPS BY EMPLOYEE REPORT AFTER EMPLOYEE REPORT	NO
11. PRINT INDIV. PLUS ON FOOD COST RPT	NO
12. AUTO CUT STRING REPORT	NO
13. PRT CLK IN/OUT ON TIME KEEPING RPT	NO
14. PRINT PLU PROFIT ON PLU REPORT	YES
CLOSE	

3. At the PLU price programming screen, enter PLU cost price relating with the cost price level.

PLU#000000000000000001 PROGRAMMING			
PLU#	000000000000000001	DESCRIPTOR	PLU1
PAGE #1	PAGE #2	PRICES	
PRC/HAL0	000001.00	PRC L1	01
PRC/HAL0	000001.10	PRC L2	02
PRC/HAL0	000001.20	PRC L3	03
PRC/HAL0	000000.90	PRC L4	04
PREV. RECORD NEXT RECORD CLOSE			

4. Register PLUs with cost prices.
5. The PLU report now prints/displays TOTAL COST, PROFIT AMOUNT and PROFIT RATE as shown in the example below:

The screenshot shows a terminal window titled "ALL PLUS REPORT" with a sub-header "X1 REPORT" and a value "0001". The main display is a table with the following columns: ITEM, GROUP#, COUNT, PLU#/%, TOTAL, TOTAL COST, PROFIT, and PROFIT RATIO. The table lists three PLUs (PLU1, PLU2, PLU3) and a TOTAL row. For PLU1, the values are: #01/#00/#00, 1, \$0.90, \$0.10, \$1.00, 10.00%. For PLU2, the values are: #01/#00/#00, 1, \$2.30, -0.30, \$2.00, 50.00%. For PLU3, the values are: #01/#00/#00, 1, \$1.00, 25.00%. The TOTAL row shows a count of 3 and a total of \$4.00. To the right of the table are five buttons: PRINT, SAVE, CLOSE, PREV, and NEXT. The buttons are arranged vertically, with PRINT, SAVE, and CLOSE at the top, and PREV and NEXT at the bottom.

ITEM	GROUP#	COUNT	PLU#/%	TOTAL	TOTAL COST	PROFIT	PROFIT RATIO
PLU1	00000000000000000001		25.00%				
#01/#00/#00	1	\$0.90	\$0.10	\$1.00	10.00%		
PLU2	00000000000000000002		50.00%				
#01/#00/#00	1	\$2.30	-0.30	\$2.00			
PLU3	00000000000000000003		25.00%				
#01/#00/#00	1	\$1.00					
TOTAL		3		\$4.00			