


SPT-3000 Drawer Module Installation Guide

Check Contents



- 1 Check whether the power of PC POS system and peripherals are turned off.
- 2 Remove connectors for peripherals and DC power supply jack.




⚠ When DC power jack is removed, the neck of the power jack should be pulled and thus removed.




- 3 Remove screws, undo lock lever and finally remove system back cover, as shown in the drawings.




- 4 Remove screws on the hard disk and cables, referring to the drawings.




- 5 Take off jumpers (2pcs) and screws from POWER PCB.



- 6 Place Hexagonal Stud and assemble Drawer PCB Module (careful with its direction & location).



- 7 Tighten up screws on Drawer PCB Module.



- 8 In order to complete assembling PC POS unit, carry out vice versa from #4.

- 9 Refer to SAM4S website for downloading Drawer Module driver and installation (<http://www.sam4s.com>).

