


SPT-3000 CF Slot Module Installation Guide

Check Contents



- 1 Check whether the power of PC POS system and peripherals are turned off.
- 2 Remove connectors for peripherals and DC power supply jack.




⚠ When DC power jack is removed, the neck of the power jack should be pulled and thus removed.



- 3 Remove screws, undo lock lever and finally remove system back cover, as shown in the drawings.




- 4 Remove screws on the hard disk and cables, as refer to the drawings.




- 5 Make a slot by cutting out the area with a dotted line, as shown in the drawings.



- 6 Remove screws (2pcs) from the set and place hexagonal studs into the same place.



- 7 Place screws (2pcs) after locating CF PCB Module, referring to the drawings. Harnesses (2pcs) should be connected to its locations on the main board.



- 8 In order to complete assembling PC POS unit, carry out vice versa from #4.

- 9 Refer to SAM4S website for downloading CF Module driver and installation (<http://www.sam4s.com>).

